
ProAccess EH



Smart Access


Quick reference quide 466574 A 59-3072-1

Install the sensors with the layout shown below.




2. Installation and wiring

[1] Drill holes to install the unit. Wiring holes are not required when using a conduit pipe.




[2] Run wires out from the pole/mounting surface before attaching the sensor housing.



[3] Loosen the screws on the top and bottom covers, and remove the covers. Do not loosen the screws completely. The screws may fall out.



When using a conduit pipe



[4] Detach the sensor unit by lifting it.




[5] Fix the sensor housing with two screws.



[6] Cut the terminal cover with scissors to make a hole according to the wire diameter. (Select the smallest possible.)





(resistive load)

[8] Install the sensor unit into the sensor housing. Rotate the sensor unit to the appropriate angle (96° to left and right).



Set by smartphone App. Follow the procedure to set up and to perform calibration. Download the smartphone App form the 2D code.



After changing settings, be sure to tap the Send icon to send the settings to the sensor.



Memorizes the background of the detection area when no pedestrians or vehicles are present. It makes the sensors performance higher and more stable.

- 4. For the operation check, use a vehicle to check the entire operation of the system.
- Slide on the top and bottom covers and tighten the according screws.







6. Operation indicator

Operation mode	Operation status	Status	Operation indicator ¹⁾
Standard operation mode	Standard operation	Standby	Solid Green
		Standby Enviromental notification	Solid Purple
		Pre-detection	Solid Yellow
		Detection	Solid Red
		Calibration uncompleted	Solid Blue
	Start up	Start up	Solid Blue (two sec)
	Factory reset	Complete	Blinking Blue(Fast)2)
Smartphone App connected mode	Standard operation	Standby	Blinking Green(Slow)
		Standby Enviromental notification	Blinking Purple(Slow)
		Pre-detection	Blinking Yellow(Slow)
		Detection	Blinking Red(Slow)
		Calibration uncompleted	Blinking Blue(Slow)
	Area check	Standby	Blinking Green3)
		Pre-detection	Blinking Yellow
		Detection	Blinking Red
	Calibration	In process	Blinking Blue & Green
		Unstable error	Blinking Red & Yellow(Fast)4/6)
		High reflection error	Blinking Red & Blue(Fast) ^{4 6)}
		High reflection	Blinking Purple5)6)

- 1) The operation indicator is always On, even if "Indicator" in App is set to "Off".
- 2) Press and hold the reset button for 5 to 10 seconds for the factory reset.
- 3) The operation indicator flashing blue for 30 seconds, it will automatically return to the normal operation mode
- Calibration has not been performed.
- 5) After blinking for 10 seconds, it returns to the status of Normal operation. Calibration is completed.
- 6) Refer P17 "7-3 Calibration" to fix this issue.

7. Compliance note

Hereby, BBC Bircher AG declares that the radio equipment type ProAccess EH is in compliance with Directive 2014/53/EU. The full text of the EU declaration of comformity is available at the following internet address: https://www.bircher.com